

Vented overflow kit 150mm instructions

Your kit will have either a Wallace seal or a uniseal, please
check as the hole size is different

150mm Uniseal = 177.8mm Holesaw

150mm Wallace = 168mm Holesaw

